



## Software Updater

Follow the below steps to update your TruCheck™ 2 or TruCheck™ 2 Plus

1. Power down the TruCheck
2. Press and Hold RESET Button (TruCheck™ 2 Plus) or ZERO Button (TruCheck™ 2)
3. Connect USB from PC to the TruCheck™
4. Display should show 'BOOT' – Release Button
5. Run 'Software\_Updater TC vX.X.X.exe' PC Program (X.X.X being the current version)
6. Select Serial Port (Choose correct COM port from drop down list)
7. Select File (Browse to Hex file 'TruCheck2 vX.X.X.hex'; X.X.X being the current version)
8. Press 'Send File' (wait a few seconds then progress bar will start to move)
9. TruCheck will Restart after Upload
10. Check S/W version in Version screen on TruCheck™